

PRINT SETTINGS MUST BE SET TO 100% / DO NOT SCALE • 8.5" x 11" LETTER

Use scissors to cut along blue line edge of gauge.

Follow instructions on cap gauge to measure cap/closure or bottle.




PHOENIX™

we've got you covered.

Suggested Cap Application Torque

CAP SIZE (mm)	TORQUE (inch/pounds)
15	6 - 9
18	7 - 10
20	8 - 12
22	9 - 14
24	10 - 16
28	12 - 18
33	15 - 25
38	17 - 26
43	18 - 27
48	19 - 30
53	21 - 36
58	23 - 40
63	25 - 43
70	28 - 50
83	40 - 60
89	45 - 65
100	50 - 70
110	52 - 73
120	55 - 75

Printable Cap Gauge



Request a reusable cap gauge at: phxpkg.com/contact